Command GPARAMETERS

PURPOSE List the actually used display parameters

FUNCTION The display parameters actually used for the last graphic display are

listed. The display parameters are the optional parameters of the commands GDISP, GPLOT, GOVER, GPRESET, GSET. This list of display parameters is sufficient to fully specify the graphic presentation

of the figure in a new SATAN session.

REMARKS The text which is listed as output of the command GPARAMETERS is

internally prepared with each GDISP, GOVER or GPLOT command. This text is added to the GRAF dataset by the command <u>GSAVE</u>.